

SAV 483.02

ZERO SETTER - THE ORIGINAL

Vertical and horizontal


APPLICATION

For adjusting the tools (e.g. milling cutter) to "zero" and for determining the reference point of the machine spindle. No damage to tools during start-up, no feeler gauge or centre finder required.

DESIGN

Spring-loaded contact pad and housing body made of hardened tool steel, precision ground. Delivered complete with dial gauge (0.01 mm reading accuracy) in rubber storage box.























3.2

